



Installation:

Remove the cover screws and remove top cover.
 Find suitable location and mount unit using proper hardware. Two mounting holes are provided for #10-12 screws.
 Connect to one or more lighted push-button switches and dome lamps per circuit and one or more tone units as required.
 Maximum lamp and tone load is 2 Amps.
 Route all wires through hole in side of enclosure.
 Connect to suitable 24 VDC power supply.
 Verify Power LED (D22) is on.
 The Tone Enable Input and Tone Enable Output allow multiple T8 devices to utilize one tone circuit for a system.
 If utilizing tone output make sure Tone Enable switch for each channel is in the "ON" position (default).
 While any switch input is active adjust the Tone Length (0-1 second) and Tone Rate (repeat 1-60 seconds).
 LED's D5, 6, 7, 8, 13, 14, 15, 16 indicate when the lamp outputs are active.
 LED D21 shows when the tone output is active.

Title		HM-18 Lamp and Tone Control Unit
Size		B
Date	August, 2004	Drawn by: jt
File name	T8instsch	Sheet 1 of 1