

TECHNICAL SPECIFICATIONS

FOUR POSITION DOME LIGHT

HM-D4

MAXIMUM VISIBILITY
7 LENS COLORS AVAILABLE
PLUG IN LENSES
FLEXIBLE INSTALLATION



Front



Rear

DESCRIPTION

Surface, wall or ceiling mounted dome lamp. Consists of a faceplate with combination lamp socket and lens holder. Lens colors available (white, green, red, blue, amber, yellow or clear).

CONTROLS AND INDICATORS

Low-power high-luminous lamps, front replaceable with rated average life of 6000 hours.

INDICATOR CONFIGURATIONS

HM-D4 provides indicators only.

LAMPS

28V at 40ma. 28ESB T-2 slide base.

INSTALLATION

Prewired connectors.
Mount using only the four 6-32 x 1" nylon screws provided.

HOUSING AND FINISH

Faceplate: Flame retardant ABS plastic rated 94V-O by UL, finished in off-white supplied with nylon mounting screws; **W42 Backbox:** metal backbox supplied by others.

DIMENSIONS

Faceplate: 4-9/16" (11.59cm) wide x 4-1/2" (11.43cm) high; **W42 Backbox:** 4-11/16" (11.91cm) square electrical backbox with two gang adapter for total depth of 3-5/16" (8.41cm), supplied by others.

LISTINGS

The HM-D4 is UL and CUL listed Hospital Signaling Equipment / Nurse Call Equipment under File E157381.

Heritage Medcall, Inc.

202 East Virginia Avenue, Tampa, FL 33603
813-221-1000 (voice), 813-223-1405 (fax)
www.heritagemedcall.com

11/07 HM-D4 Issue C
Printed in U.S.A.

ARCHITECTS' AND ENGINEERS' SPECIFICATIONS

MODEL HM-D4 FOUR POSITION DOME LIGHT

The wall recessed or surface mounted Model HM-D4 Four Lamp Dome Panel shall provide visual indication for system status via indicators.

The HM-D4 shall be UL and CUL listed Hospital Signaling Equipment / Nurse Call Equipment under File E157381.

The panel shall be provided with low-power high-luminous indicators, lamps shall be front replaceable with an average life of 6000 hours. Lens colors shall be available (separately).

The HM-D4 shall be feature indicator only.

Faceplate shall be flame retardant ABS plastic rated 94V-O by UL, finished in off-white.

The dome light panel shall mount onto a backbox or surface housing with four nylon screws furnished. The unit shall be prewired for ease of installation.

Faceplate shall mount to backbox with four 6-32 x 1" nylon screws provided.

Dome Light panel shall install into a two gang box for surface or wall flush mounting. The dimensions shall be: **Faceplate** - 4-9/16" (11.59cm) wide x 4-1/2" (11.43cm) high; **W42 backbox** - 4-11/16" (11.91cm) square electrical backbox with two gang adapter for total depth of 3-5/16" (8.41cm), supplied by others.