

TECHNICAL SPECIFICATIONS

SINGLE PATIENT STATION

HM-SPS

Call Placement Indicator
Call Reset Button
Cordset Removal Triggers Call Placement
Standard Cordset Receptacle
UL Listed



Front



Rear



Side

DESCRIPTION

Wall recessed or surface mounted single patient station for use with remote call origination cordset. Removal of the cordset originates a call placement.

RECEPTACLE

One cordset receptacle wired to accept a single 1/4" cordset (normal call, geriatric, explosion proof) with nurse call origination facility.

CONTROLS AND INDICATORS

One combination white call placement indicator and call cancel button.

INSTALLATION

Color-coded, prewired terminations provided. Mount using only the two 6-32 x 1" nylon screws provided.

HOUSING AND FINISH

Faceplate: Flame retardant ABS plastic rated 94V-O by UL, finished in off-white supplied with nylon mounting screws.

W41 Backbox: metal backbox supplied by others.

DIMENSIONS

Faceplate: 2-3/4" (6.99cm) wide x 4-1/2" (11.43cm) high.

W41 Backbox: 4-11/16" (11.91cm) square electrical box with one-gang adapter for a total depth of 2-7/8" (7.30cm), supplied by others.

LISTINGS

The HM-SPS is UL and CUL listed Hospital Signaling Equipment / Nurse Call Equipment under File E157381.

Heritage Medcall, Inc.

202 East Virginia Avenue, Tampa, FL 33603
813-221-1000 (voice), 813-223-1405 (fax)
www.heritagemedcall.com

ARCHITECTS' AND ENGINEERS' SPECIFICATIONS

MODEL HM-SPS SINGLE PATIENT STATION

The wall recessed or surface mounted single patient station shall be for use with remote call origination cordset.

The patient station shall be provided with a white combination call placement indicator and call cancel button. A receptacle shall be provided, to accept single 1/4" type cordsets. A call shall be originated if the cordset is removed from the receptacle.

The unit shall be provided with color-coded prewired terminations for ease of installation. The faceplate shall be flame retardant ABS plastic rated 94V-O by UL. Nylon Screws shall be provided to mount the faceplate.

The unit shall be UL and CUL listed Hospital Signaling Equipment / Nurse Call Equipment under File E157381.

The faceplate shall be finished in off-white. The W41 backbox shall be supplied by others. The dimensions shall be: **Faceplate:** 2-3/4" (6.99cm) wide x 4-1/2" (11.43cm) high, **W41 backbox:** 4-11/16" (11.91cm) square electrical box with one-gang adapter for total depth of 2-7/8" (7.30cm), supplied by others.