

Heritage MedCall Technical Specifications

MODEL HM-PBCC-8 8' BED CORD

1/4" PHONO PLUG

MOMENTARY OPERATION

CORD CLIP FOR SECURING TO BED
OR PATIENT CLOTHES

EASY CLEAN FINISH



DESCRIPTION:

The Heritage Model HM-PBCC-8 is an 8' momentary call switch for use with the Model HM-671, HM-SPS or HM-DPS to allow call placement from a bed or chair. The Bed-Cord is fitted with a clasp for securing the cord to the bed or patient clothes.

RESET:

Emergency call station reset is accomplished by pressing the CHECK-IN or CANCEL button on the HM-527 or HM-S(D)PS panel. All emergency calls require this reset action to assure all calls are verified and all initiating locations are visited.

INSTALLATION:

Model HM-PBCC-8 is installed by fully inserting the 1/4" phone plug into the bed-cord wall plate. Removing the bed-cord from the wall plate will initiate an emergency call